





























Bravo Still


Extract fans















- Motion sensor

Lineup	Connected air duct size, mm	Rated power, W	Maximum airflow, m ³ /h	Sound pressure level LpA at 3 m, dB(A)	Motion sensor	Pull cord	Humidity sensor	Timer	Article	Number of speeds
 Bravo Still 100	100	5.6	70	26	✗	✗	✗	✗	8006203	1
 Bravo Still 100 S	100	5.6	70	26	✗	✓	✗	✗	8006241	1
 Bravo Still 100 T	100	5.6	70	26	✗	✗	✗	Turn off timer	8006272	1
 Bravo Still 100 ST	100	5.6	70	26	✗	✓	✗	Turn off timer	8006265	1
 Bravo Still 100 H	100	5.6	70	26	✗	✗	✓	Turn off timer	8006227	1
 Bravo Still 100 SH	100	5.6	70	26	✗	✓	✓	Turn off timer	8006258	1
 Bravo Still 100 IR	100	5.6	70	26	✓	✗	✗	Turn off timer	8006234	1

 Bravo Still 125	125	9.3	115	31	✗	✗	✗	✗	8006289	1
 Bravo Still 125 IR	125	9.3	115	31	✓	✗	✗	Turn off timer	8006319	1
 Bravo Still 125 SH	125	9.3	115	31	✗	✓	✓	Turn off timer	8006333	1
 Bravo Still 125 H	125	9.3	115	31	✗	✗	✓	Turn off timer	8006302	1
 Bravo Still 125 ST	125	9.3	115	31	✗	✓	✗	Turn off timer	8006340	1
 Bravo Still 125 T	125	9.3	115	31	✗	✗	✗	Turn off timer	8006357	1
 Bravo Still 125 S	125	9.3	115	31	✗	✓	✗	✗	8006326	1
 Bravo Still 150	150	20	235	35	✗	✗	✗	✗	8006364	1
 Bravo Still 150 S	150	20	235	35	✗	✓	✗	✗	8006401	1
 Bravo Still 150 T	150	20	235	35	✗	✗	✗	Turn off timer	8006432	1
 Bravo Still 150 ST	150	20	235	35	✗	✓	✗	Turn off timer	8006425	1
 Bravo Still 150 H	150	20	235	35	✗	✗	✓	Turn off timer	8006388	1
 Bravo Still 150 SH	150	20	235	35	✗	✓	✓	Turn off timer	8006418	1
 Bravo Still 150 IR	150	20	235	35	✓	✗	✗	Turn off timer	8006395	1

	Bravo Still Chrome 100 S	100	5.6	70	26	✗	✓	✗	✗		1
	Bravo Still Chrome 100 T	100	5.6	70	26	✗	✗	✗	Turn off timer		1
	Bravo Still Chrome 100 ST	100	5.6	70	26	✗	✓	✗	Turn off timer		1
	Bravo Still Chrome 100 H	100	5.6	70	26	✗	✗	✓	Turn off timer		1
	Bravo Still Chrome 100 IR	100	5.6	70	26	✓	✗	✗	Turn off timer		1
	Bravo Still Chrome 100 SH	100	5.6	70	26	✗	✓	✓	Turn off timer		1
	Bravo Still Chrome 100	100	5.6	70	26	✗	✗	✗	✗	8037542	1
	Bravo Still Chrome 125	125	9.3	115	31	✗	✗	✗	✗	8037559	1
	Bravo Still Chrome 125 S	125	9.3	115	31	✗	✓	✗	✗		1
	Bravo Still Chrome 125 T	125	9.3	115	31	✗	✗	✗	Turn off timer		1
	Bravo Still Chrome 125 ST	125	9.3	115	31	✗	✓	✗	Turn off timer		1
	Bravo Still Chrome 125 H	125	9.3	115	31	✗	✗	✓	Turn off timer		1
	Bravo Still Chrome 125 SH	125	9.3	115	31	✗	✓	✓	Turn off timer		1
	Bravo Still Chrome 125 IR	125	9.3	115	31	✓	✗	✗	Turn off timer		1

	Bravo Still Chrome 150 SH	150	20	235	35	✗	✓	✓	Turn off timer		1
	Bravo Still Chrome 150 H	150	20	235	35	✗	✗	✓	Turn off timer		1
	Bravo Still Chrome 150 ST	150	20	235	35	✗	✓	✗	Turn off timer		1
	Bravo Still Chrome 150 T	150	20	235	35	✗	✗	✗	Turn off timer		1
	Bravo Still Chrome 150 S	150	20	235	35	✗	✓	✗	✗		1
	Bravo Still Chrome 150	150	20	235	35	✗	✗	✗	✗	8037573	1
	Bravo Still Chrome 150 IR	150	20	235	35	✓	✗	✗	Turn off timer		1
	Bravo Still Platinum 100 IR	100	5.6	70	26	✓	✗	✗	Turn off timer		1
	Bravo Still Platinum 100 ST	100	5.6	70	26	✗	✓	✗	Turn off timer		1
	Bravo Still Platinum 100 H	100	5.6	70	26	✗	✗	✓	Turn off timer		1
	Bravo Still Platinum 100 SH	100	5.6	70	26	✗	✓	✓	Turn off timer		1
	Bravo Still Platinum 100 T	100	5.6	70	26	✗	✗	✗	Turn off timer		1
	Bravo Still Platinum 100 S	100	5.6	70	26	✗	✓	✗	✗		1
	Bravo Still Platinum 100	100	5.6	70	26	✗	✗	✗	✗	8006449	1

	Bravo Still Platinum 125	125	9.3	115	31	✗	✗	✗	✗	8038273	1
	Bravo Still Platinum 125 H	125	9.3	115	31	✗	✗	✓	Turn off timer		1
	Bravo Still Platinum 125 SH	125	9.3	115	31	✗	✓	✓	Turn off timer		1
	Bravo Still Platinum 125 IR	125	9.3	115	31	✓	✗	✗	Turn off timer		1
	Bravo Still Platinum 125 ST	125	9.3	115	31	✗	✓	✗	Turn off timer		1
	Bravo Still Platinum 125 T	125	9.3	115	31	✗	✗	✗	Turn off timer		1
	Bravo Still Platinum 125 S	125	9.3	115	31	✗	✓	✗	✗		1
	Bravo Still Platinum 150	150	20	235	35	✗	✗	✗	✗	8038280	1
	Bravo Still Platinum 150 S	150	20	235	35	✗	✓	✗	✗		1
	Bravo Still Platinum 150 T	150	20	235	35	✗	✗	✗	Turn off timer		1
	Bravo Still Platinum 150 ST	150	20	235	35	✗	✓	✗	Turn off timer		1
	Bravo Still Platinum 150 H	150	20	235	35	✗	✗	✓	Turn off timer		1
	Bravo Still Platinum 150 SH	150	20	235	35	✗	✓	✓	Turn off timer		1
	Bravo Still Platinum 150 IR	150	20	235	35	✓	✗	✗	Turn off timer		1