










Bravo

Extract fans

- Motion sensor






| Lineup | Connected air duct size, mm | Rated power, W | Maximum airflow, m ³ /h | Sound pressure level LpA at 3 m, dB(A) | Motion sensor | Pull cord | Humidity sensor | Timer | Article | Number of speeds |
|--|-----------------------------|----------------|------------------------------------|--|---------------|-----------|-----------------|----------------|---------|------------------|
|  Bravo 100 | 100 | 14 | 101 | 35 | ✗ | ✗ | ✗ | ✗ | 8005176 | 1 |
|  Bravo 100 S | 100 | 14 | 101 | 35 | ✗ | ✓ | ✗ | ✗ | 8005305 | 1 |
|  Bravo 100 T | 100 | 14 | 101 | 35 | ✗ | ✗ | ✗ | Turn off timer | 8005404 | 1 |
|  Bravo 100 ST | 100 | 14 | 101 | 35 | ✗ | ✓ | ✗ | Turn off timer | 8005374 | 1 |
|  Bravo 100 H | 100 | 14 | 101 | 35 | ✗ | ✗ | ✓ | Turn off timer | 8005244 | 1 |
|  Bravo 100 SH | 100 | 14 | 101 | 35 | ✗ | ✓ | ✓ | Turn off timer | 8005343 | 1 |
|  Bravo 100 IR | 100 | 14 | 101 | 35 | ✓ | ✗ | ✗ | ✗ | 8005275 | 1 |

| | | | | | | | | | | |
|--|-----|----|-----|----|---|---|---|----------------|---------|---|
|  Bravo 125 | 125 | 16 | 192 | 37 | × | × | × | × | 8005442 | 1 |
|  Bravo 125 S | 125 | 16 | 192 | 37 | × | ✓ | × | × | 8005565 | 1 |
|  Bravo 125 T | 125 | 16 | 192 | 37 | × | × | × | Turn off timer | 8005657 | 1 |
|  Bravo 125 ST | 125 | 16 | 192 | 37 | × | ✓ | × | Turn off timer | 8005626 | 1 |
|  Bravo 125 H | 125 | 16 | 192 | 37 | × | × | ✓ | Turn off timer | 8005503 | 1 |
|  Bravo 125 SH | 125 | 16 | 192 | 37 | × | ✓ | ✓ | Turn off timer | 8005602 | 1 |
|  Bravo 125 IR | 125 | 16 | 192 | 37 | ✓ | × | × | × | 8005534 | 1 |
|  Bravo 150 | 150 | 24 | 305 | 39 | × | × | × | × | 8005701 | 1 |
|  Bravo 150 S | 150 | 24 | 305 | 39 | × | ✓ | × | × | 8005817 | 1 |
|  Bravo 150 T | 150 | 24 | 305 | 39 | × | × | × | Turn off timer | 8005893 | 1 |
|  Bravo 150 ST | 150 | 24 | 305 | 39 | × | ✓ | × | Turn off timer | 8005862 | 1 |
|  Bravo 150 H | 150 | 24 | 305 | 39 | × | × | ✓ | Turn off timer | 8005756 | 1 |
|  Bravo 150 SH | 150 | 24 | 305 | 39 | × | ✓ | ✓ | Turn off timer | 8005848 | 1 |
|  Bravo 150 IR | 150 | 24 | 305 | 39 | ✓ | × | × | × | 8005787 | 1 |
|  Bravo Chrome 100 | 100 | 14 | 101 | 35 | × | × | × | × | 8005947 | 1 |

| | | | | | | | | | | | |
|---|---------------------|-----|----|-----|----|---|---|---|----------------|---------|---|
|  | Bravo Chrome 100 S | 100 | 14 | 101 | 35 | × | ✓ | × | × | 8005992 | 1 |
|  | Bravo Chrome 100 T | 100 | 14 | 101 | 35 | × | × | × | Turn off timer | 8006029 | 1 |
|  | Bravo Chrome 100 ST | 100 | 14 | 101 | 35 | × | ✓ | × | Turn off timer | 8006012 | 1 |
|  | Bravo Chrome 100 H | 100 | 14 | 101 | 35 | × | × | ✓ | Turn off timer | 8005978 | 1 |
|  | Bravo Chrome 100 SH | 100 | 14 | 101 | 35 | × | ✓ | ✓ | Turn off timer | 8006005 | 1 |
|  | Bravo Chrome 100 IR | 100 | 14 | 101 | 35 | ✓ | × | × | × | 8005985 | 1 |
|  | Bravo Chrome 125 | 125 | 16 | 192 | 37 | × | × | × | × | 8006036 | 1 |
|  | Bravo Chrome 125 S | 125 | 16 | 192 | 37 | × | ✓ | × | × | 8006074 | 1 |
|  | Bravo Chrome 125 T | 125 | 16 | 192 | 37 | × | × | × | Turn off timer | 8006104 | 1 |
|  | Bravo Chrome 125 ST | 125 | 16 | 192 | 37 | × | ✓ | × | Turn off timer | 8006098 | 1 |
|  | Bravo Chrome 125 H | 125 | 16 | 192 | 37 | × | × | ✓ | Turn off timer | 8006050 | 1 |
|  | Bravo Chrome 125 SH | 125 | 16 | 192 | 37 | × | ✓ | ✓ | Turn off timer | 8006081 | 1 |
|  | Bravo Chrome 125 IR | 125 | 16 | 192 | 37 | ✓ | × | × | × | 8006067 | 1 |
|  | Bravo Chrome 150 | 150 | 24 | 305 | 39 | × | × | × | × | 8006111 | 1 |
|  | Bravo Chrome 150 S | 150 | 24 | 305 | 39 | × | ✓ | × | × | 8006159 | 1 |

| | | | | | | | | | | | |
|---|-----------------------|-----|----|-----|----|---|---|---|----------------|---------|---|
|  | Bravo Chrome 150 T | 150 | 24 | 305 | 39 | × | × | × | Turn off timer | 8006180 | 1 |
|  | Bravo Chrome 150 ST | 150 | 24 | 305 | 39 | × | ✓ | × | Turn off timer | 8006173 | 1 |
|  | Bravo Chrome 150 H | 150 | 24 | 305 | 39 | × | × | ✓ | Turn off timer | 8006135 | 1 |
|  | Bravo Chrome 150 SH | 150 | 24 | 305 | 39 | × | ✓ | ✓ | Turn off timer | 8006166 | 1 |
|  | Bravo Chrome 150 IR | 150 | 24 | 305 | 39 | ✓ | × | × | × | 8006142 | 1 |
|  | Bravo Platinum 100 | 100 | 14 | 101 | 35 | × | × | × | × | 8006197 | 1 |
|  | Bravo Platinum 100 S | 100 | 14 | 101 | 35 | × | ✓ | × | × | | 1 |
|  | Bravo Platinum 100 T | 100 | 14 | 101 | 35 | × | × | × | Turn off timer | | 1 |
|  | Bravo Platinum 100 ST | 100 | 14 | 101 | 35 | × | ✓ | × | Turn off timer | | 1 |
|  | Bravo Platinum 100 H | 100 | 14 | 101 | 35 | × | × | ✓ | Turn off timer | | 1 |
|  | Bravo Platinum 100 SH | 100 | 14 | 101 | 35 | × | ✓ | ✓ | Turn off timer | 8032615 | 1 |
|  | Bravo Platinum 100 IR | 100 | 14 | 101 | 35 | ✓ | × | × | × | | 1 |
|  | Bravo Platinum 125 | 125 | 16 | 192 | 37 | × | × | × | × | 8039560 | 1 |
|  | Bravo Platinum 125 S | 125 | 16 | 192 | 37 | × | ✓ | × | × | | 1 |
|  | Bravo Platinum 125 T | 125 | 16 | 192 | 37 | × | × | × | Turn off timer | | 1 |

| | | | | | | | | | | |
|--|-----|----|-----|----|---|---|---|----------------|---------|---|
|  Bravo Platinum 125 ST | 125 | 16 | 192 | 37 | ✗ | ✓ | ✗ | Turn off timer | | 1 |
|  Bravo Platinum 125 H | 125 | 16 | 192 | 37 | ✗ | ✗ | ✓ | Turn off timer | | 1 |
|  Bravo Platinum 125 SH | 125 | 16 | 192 | 37 | ✗ | ✓ | ✓ | Turn off timer | | 1 |
|  Bravo Platinum 125 IR | 125 | 16 | 192 | 37 | ✓ | ✗ | ✗ | ✗ | | 1 |
|  Bravo Platinum 150 | 150 | 24 | 305 | 39 | ✗ | ✗ | ✗ | ✗ | 8039577 | 1 |
|  Bravo Platinum 150 S | 150 | 24 | 305 | 39 | ✗ | ✓ | ✗ | ✗ | | 1 |
|  Bravo Platinum 150 T | 150 | 24 | 305 | 39 | ✗ | ✗ | ✗ | Turn off timer | | 1 |
|  Bravo Platinum 150 ST | 150 | 24 | 305 | 39 | ✗ | ✓ | ✗ | Turn off timer | | 1 |
|  Bravo Platinum 150 H | 150 | 24 | 305 | 39 | ✗ | ✗ | ✓ | Turn off timer | | 1 |
|  Bravo Platinum 150 SH | 150 | 24 | 305 | 39 | ✗ | ✓ | ✓ | Turn off timer | | 1 |
|  Bravo Platinum 150 IR | 150 | 24 | 305 | 39 | ✓ | ✗ | ✗ | ✗ | | 1 |
|  Bravo 100 (127-220V/60Hz) | 100 | | | | ✗ | ✗ | ✗ | ✗ | | 1 |
|  Bravo 125 (127-220V/60Hz) | 125 | | | | ✗ | ✗ | ✗ | ✗ | | 1 |
|  Bravo 150 (127-220V/60Hz) | 150 | | | | ✗ | ✗ | ✗ | ✗ | | 1 |
|  Bravo Chrome 100 (127-220V/60Hz) | 100 | | | | ✗ | ✗ | ✗ | ✗ | | 1 |

| | | | | | | | | | | |
|--|-----|--|--|--|---|---|---|---|--|---|
|  Bravo Chrome 125 (127-220V/60Hz) | 125 | | | | × | × | × | × | | 1 |
|  Bravo Chrome 150 (127-220V/60Hz) | 150 | | | | × | × | × | × | | 1 |
|  Bravo Platinum 100 (127-220V/60Hz) | 100 | | | | × | × | × | × | | 1 |
|  Bravo Platinum 125 (127-220V/60Hz) | 125 | | | | × | × | × | × | | 1 |
|  Bravo Platinum 150 (127-220V/60Hz) | 150 | | | | × | × | × | × | | 1 |