

Bravo

Extract fans

- Humidity sensor
- Motion sensor

Lineup	Connected air duct size, mm	Rated power, W	Maximum airflow, m³/h	Sound pressure level LpA at 3 m, dB(A)	Motion sensor	Pull cord	Humidity sensor	Timer	Number of speeds
Bravo 100	100	14	101	35	✗	✗	✗	✗	1
Bravo 100 S	100	14	101	35	✗	✓	✗	✗	1
Bravo 100 T	100	14	101	35	✗	✗	✗	Turn off timer	1
Bravo 100 ST	100	14	101	35	✗	✓	✗	Turn off timer	1
Bravo 100 H	100	14	101	35	✗	✗	✓	Turn off timer	1
Bravo 100 SH	100	14	101	35	✗	✓	✓	Turn off timer	1
Bravo 100 IR	100	14	101	35	✓	✗	✗	✗	1

 Bravo 125	125	16	192	37	✗	✗	✗	✗	1
 Bravo 125 S	125	16	192	37	✗	✓	✗	✗	1
 Bravo 125 T	125	16	192	37	✗	✗	✗	Turn off timer	1
 Bravo 125 ST	125	16	192	37	✗	✓	✗	Turn off timer	1
 Bravo 125 H	125	16	192	37	✗	✗	✓	Turn off timer	1
 Bravo 125 SH	125	16	192	37	✗	✓	✓	Turn off timer	1
 Bravo 125 IR	125	16	192	37	✓	✗	✗	✗	1
 Bravo 150	150	24	305	39	✗	✗	✗	✗	1
 Bravo 150 S	150	24	305	39	✗	✓	✗	✗	1
 Bravo 150 T	150	24	305	39	✗	✗	✗	Turn off timer	1
 Bravo 150 ST	150	24	305	39	✗	✓	✗	Turn off timer	1
 Bravo 150 H	150	24	305	39	✗	✗	✓	Turn off timer	1
 Bravo 150 SH	150	24	305	39	✗	✓	✓	Turn off timer	1
 Bravo 150 IR	150	24	305	39	✓	✗	✗	✗	1

 Bravo Chrome 100	100	14	101	35	✗	✗	✗	✗	1
 Bravo Chrome 100 S	100	14	101	35	✗	✓	✗	✗	1
 Bravo Chrome 100 T	100	14	101	35	✗	✗	✗	Turn off timer	1
 Bravo Chrome 100 ST	100	14	101	35	✗	✓	✗	Turn off timer	1
 Bravo Chrome 100 H	100	14	101	35	✗	✗	✓	Turn off timer	1
 Bravo Chrome 100 SH	100	14	101	35	✗	✓	✓	Turn off timer	1
 Bravo Chrome 100 IR	100	14	101	35	✓	✗	✗	✗	1
 Bravo Chrome 125	125	16	192	37	✗	✗	✗	✗	1
 Bravo Chrome 125 S	125	16	192	37	✗	✓	✗	✗	1
 Bravo Chrome 125 T	125	16	192	37	✗	✗	✗	Turn off timer	1
 Bravo Chrome 125 ST	125	16	192	37	✗	✓	✗	Turn off timer	1
 Bravo Chrome 125 H	125	16	192	37	✗	✗	✓	Turn off timer	1
 Bravo Chrome 125 SH	125	16	192	37	✗	✓	✓	Turn off timer	1
 Bravo Chrome 125 IR	125	16	192	37	✓	✗	✗	✗	1

 Bravo Chrome 150	150	24	305	39	✗	✗	✗	✗	1
 Bravo Chrome 150 S	150	24	305	39	✗	✓	✗	✗	1
 Bravo Chrome 150 T	150	24	305	39	✗	✗	✗	Turn off timer	1
 Bravo Chrome 150 ST	150	24	305	39	✗	✓	✗	Turn off timer	1
 Bravo Chrome 150 H	150	24	305	39	✗	✗	✓	Turn off timer	1
 Bravo Chrome 150 SH	150	24	305	39	✗	✓	✓	Turn off timer	1
 Bravo Chrome 150 IR	150	24	305	39	✓	✗	✗	✗	1
 Bravo Platinum 100	100	14	101	35	✗	✗	✗	✗	1
 Bravo Platinum 100 S	100	14	101	35	✗	✓	✗	✗	1
 Bravo Platinum 100 T	100	14	101	35	✗	✗	✗	Turn off timer	1
 Bravo Platinum 100 ST	100	14	101	35	✗	✓	✗	Turn off timer	1
 Bravo Platinum 100 H	100	14	101	35	✗	✗	✓	Turn off timer	1
 Bravo Platinum 100 SH	100	14	101	35	✗	✓	✓	Turn off timer	1
 Bravo Platinum 100 IR	100	14	101	35	✓	✗	✗	✗	1

 Bravo Platinum 125	125	16	192	37	✗	✗	✗	✗	1
 Bravo Platinum 125 S	125	16	192	37	✗	✓	✗	✗	1
 Bravo Platinum 125 T	125	16	192	37	✗	✗	✗	Turn off timer	1
 Bravo Platinum 125 ST	125	16	192	37	✗	✓	✗	Turn off timer	1
 Bravo Platinum 125 H	125	16	192	37	✗	✗	✓	Turn off timer	1
 Bravo Platinum 125 SH	125	16	192	37	✗	✓	✓	Turn off timer	1
 Bravo Platinum 125 IR	125	16	192	37	✓	✗	✗	✗	1
 Bravo Platinum 150	150	24	305	39	✗	✗	✗	✗	1
 Bravo Platinum 150 S	150	24	305	39	✗	✓	✗	✗	1
 Bravo Platinum 150 T	150	24	305	39	✗	✗	✗	Turn off timer	1
 Bravo Platinum 150 ST	150	24	305	39	✗	✓	✗	Turn off timer	1
 Bravo Platinum 150 H	150	24	305	39	✗	✗	✓	Turn off timer	1
 Bravo Platinum 150 SH	150	24	305	39	✗	✓	✓	Turn off timer	1
 Bravo Platinum 150 IR	150	24	305	39	✓	✗	✗	✗	1

 Bravo 100 (127-220V/60Hz)	100				✖	✖	✖	✖	1
 Bravo 125 (127-220V/60Hz)	125				✖	✖	✖	✖	1
 Bravo 150 (127-220V/60Hz)	150				✖	✖	✖	✖	1
 Bravo Chrome 100 (127-220V/60Hz)	100				✖	✖	✖	✖	1
 Bravo Chrome 125 (127-220V/60Hz)	125				✖	✖	✖	✖	1
 Bravo Chrome 150 (127-220V/60Hz)	150				✖	✖	✖	✖	1
 Bravo Platinum 100 (127-220V/60Hz)	100				✖	✖	✖	✖	1
 Bravo Platinum 125 (127-220V/60Hz)	125				✖	✖	✖	✖	1
 Bravo Platinum 150 (127-220V/60Hz)	150				✖	✖	✖	✖	1