

PP 160

OUTER VENTILATION HOOD MOUNTING FROM INSIDE


Features

- The outer hood is designed to prevent the ingress of water and large objects into the ventilation equipment from outside.
- Pre-installed with a hood the air duct is mounted in a hole drilled in the wall. The installation is done from the inside.
- Special design allows installation of the hood by the operator on a wall
 of high-rise buildings and enables airtight sealing of the air duct in the
 core hole




Design


- Made of high-quality incombustible ultraviolet resistant plastic.
- Fixation at the end of the air duct with latches.
- o The ventilation hood [1] is equipped with a silicone sealing ring [2] that provides high sealing integrity of the air duct [3] in the wall.
- The air duct with diameter of 160 mm is made of high-quality PVC plastic.



Heat and moisture regeneration

- Drill a hole with a diameter of 180 mm in the wall.
- Insert the hood into the wall core hole and push it until the sealing ring appears on the outer side.
- Pull the hood in the opposite direction so the silicone sealing ring provides tight seal between the hood and the wall.
- Install the air duct with the minimum slope of 2–3° downwards using foam wedges from the delivery set.
- The air duct must be fixed in the wall core hole using mounting foam.









Overall dimensions [mm]

Model	Air duct length
PP 160/0.3	300
PP 160/0.5	500
PP 160/0.7	700
PP 160/0.8	800





116 blaubergventilatoren.de